



Two-stop vertical platform lift for a variety of indoor or outdoor applications

Reliable operation with robust components

Specialized models for commercial applications such as stage access or mobile use

Savaria™ Multilift Vertical Platform Lift

VALUE AND RELIABILITY



The Savaria Multilift has long been a reliable vertical platform lift for deck or porch access. Built for lasting durability and weather extremes, the Multilift carries up to 750 lbs. Its ACME screw drive provides reliable day-to-day operation and precision of movement. Now available in five models, including a fully enclosed version and a stainless steel clad unit, the Multilift is truly multi-purpose. Suitable for commercial installations in the US and home use anywhere, this lift provides great value and simplicity of installation for a huge new range of applications.



SAVARIA™ MULTILIFT VERTICAL PLATFORM LIFT

All Multilifts handle up to 750 lbs (340 kg) and travel smoothly at a nominal speed of 8 feet per minute. The standard and enclosed models can be optionally configured with a 90 degree exit. All Multilifts carry a 3-year parts warranty, see your dealer for full details.

STANDARD

For basic deck or porch access, choose the standard model. It's up for the challenge of tough climate conditions. Travel up to 72" with 2 stops, and choose from three platform sizes. Optional gates or doors with glass or acrylic inserts can be added. This unit is also available in 12 VDC for home use only.

Choose a specialized model for stage use, mobile applications, or when a stainless steel finish answers your needs. The base and enclosed Multilift models can be customized with a variety of options for gates, doors and automatic operation. All lifts use constant pressure operation with controls onboard the lift. Even add a second operating panel or joystick for users with reduced hand dexterity.

ENCLOSURE

This unit is fully enclosed with aluminum. Glass or acrylic inserts can be added, as well as a domed, ventilated roof. Suitable for an outdoor application to protect the user from the weather, this lift is also ideal for indoor applications with its self-supporting tower. Shipped partially assembled, this unit features easy installation with anchorage to a concrete pad the only required construction for installation.

SELF-ENCLOSED DRIVE TOWER

All Multilift models feature a self-supporting base and tower structure that houses mechanical components keeping them protected and making for simplicity of installation.

RELIABLE AND EASY OPERATION

The ACME screw drive with back-up nut provides strength and precision of movement for day-to-day use. Robust



MOBILE

This unit can be moved to provide accessibility where and when you need it. The Multilift mobile version features a 36" x 48" platform with two platform gates, automatic access ramp and travel distance up to 48". This model requires a standard 110 volt power source.

3G/THREE-GATE

The Multilift 3-gate system is ideal for stages, courtrooms, or other applications where a full enclosure is not desirable due to construction concerns or because a full enclosure would obstruct the surrounding view. The fixed side walls and landing gate create a partial enclosure for complete safety when the lift is in use, with minimal obstruction and no construction required. The lift travels up to 48" and features a 36" x 54" platform.

STAINLESS STEEL

This model is sleekly designed with the easy care of stainless; a great solution for a modern commercial or home setting. The unit is clad in stainless steel and includes side guards, handrail, call/send stations and platform gates. An automatic access ramp is also included on the 36" x 54" platform, with a travel distance of up to 48".

components are built to withstand weather extremes.

SAFETY FEATURES

Savaria Multilifts include a range of safety features to ensure safe operation for users and those around the lift. Units feature an emergency stop button on the lift, underpan obstruction sensors (not applicable on the enclosed model), non-skid zinc-coated platform and a manual lowering crank.

FINISH

With the exception of the stainless clad model, all lifts are finished in durable beige powdercoat paint. The standard and enclosed units can be enhanced with glass or acrylic door or gate inserts.

COMMERCIAL USE

Depending on the region, the Savaria Multilift is approved for use in public buildings. Some models offer an ADA-compliant platform size. Check with your local Savaria dealer for complete details.

OPTIONS

Add call/send stations, a second operating panel, joystick, wired hand pendant or 60 mm button to suit operating needs. A battery back-up operating system (24 VDC) can be added to the standard or enclosed models to allow full functionality of the lift for emergencies. These models can also be customized with a grab rail, a variety of doors including steel fire-rated, low profile aluminum doors or gates with glass or acrylic inserts, or wooden doors. An ADA handsfree telephone can also be added.

Savaria™ Multilift Vertical Platform Lift

VALUE AND RELIABILITY

SPECIFICATIONS BY MODEL

	Standard	Enclosure	Mobile	Stainless steel	3G
Standard platform sizes	34" x 48" 34" x 54" 34" x 60" (86.4 cm x 121.9 cm) (86.4 cm x 137.1 cm) (86.4 cm x 152.4 cm) 36" width platform O	36" x 48" 36" x 54" 36" x 60" (91.4 cm x 121.9 cm) (91.4 cm x 137.1 cm) (91.4 cm x 152.4 cm)	36" x 48" (91.4 cm x 121.9 cm)	36" x 54" (91.4 cm x 137.1 cm)	36" x 54" (91.4 cm x 137.1 cm)
Maximum travel	48" (121.9 cm) S 72" (182.9 cm) O	48" (121.9 cm) S 72" (182.9 cm) O	48" (121.9 cm)	48" (121.9 cm)	48" (121.9 cm)
Enclosure type	None	Full	None	None	Partial
Platform gates	All optional*	N/A	2	1	1
Landing gates/doors	All optional*	Lower landing door S All others optional*	N/A	Upper landing gate S	Lower and upper landing gates S
Automated options	Swing door, platform gate operator	Door or gate operator (upper landing), door operator (lower landing)	None	None	Gate operator (upper landing)
Access Ramp	Auto S Fixed O	Fixed O	Auto S	Auto S Fixed O	Fixed O
Motor	1 hp	¾ hp, ½ hp on 12 VDC	1 hp	1 hp	1 hp
Power	110 AC S 220 AC or 12 VDC† O 24 V battery back-up O	110 AC S 220 AC or 12 VDC† O 24 V battery back-up O	110 AC	110 AC	110 AC
Finish	Beige powdercoat	Beige powdercoat	Beige powdercoat	Clad #4 stainless steel	Beige powdercoat

S-Standard, O-Optional

*aluminum door(s), fire rated Pro auto or manual door, flush wooden door

†home use only

The Multilift complies with ASME A18.1(USA) and B.613 (Canada).

Please note, the Multilift is not available for commercial installations in Canada.

For drawings, detailed specifications and a complete list of options for your Savaria Multilift vertical platform lift, consult your local authorized Savaria dealer. To locate a dealer near you, visit savaria.com, or call us.

Talk to a Savaria dealer about how the Multilift can give you the access you need.

Authorized Savaria dealer:



www.savaria.com

2 Walker Drive, Brampton, ON L6T 5E1 Canada

tel: 800.661.5112 fax: 905.791.2222